

Installation Quick Start Guide:

Liberty CodeConnect™ enabled Wallbox Pulsar Plus Charger



Applicable Model: Liberty PN CCM-WBPM-001

IMPORTANT: Read this guide entirely before beginning installation. **Safety First!** Adhere to all safety instructions found on all installation manuals.

1. Mechanical Installation of Pedestal

Follow the instructions, from page 20 to page 38 in the *Eiffel Basic Pedestal Installation Guide* to install the pedestal. Guide is here: <https://tinyurl.com/4n9e8mvt> or via this QR code



2. Mechanical Installation of CodeConnect™ Wallbox Unit to Pedestal

The *Mechanical Installation Guide* covers the installation of the rain guard backing plate, keypad box, and EV charger to the pedestal: <https://tinyurl.com/2tpkkzdx> or via this QR code



3. Wallbox Charger Electrical Installation

Refer to "Hardwired Installation - Installation of your Wallbox charger with a permanent power supply for Rear Connection" on pages 14 and 15 of the *Wallbox Installation Guide* found here: <https://tinyurl.com/mr3sadjf> or via this QR code



4. Commissioning the CodeConnect™ Wallbox Charger

Follow the instructions in the manual linked in step #3 to energize the charger. Do not connect to Wifi or the Wallbox app, as charger management is handled by Liberty. To commission the CodeConnect™ charger:

1. **Charger Registration:** Call the Liberty technical line at (855) 387-3783 to register the charger.
2. **Serial Number Verification:** Provide the Liberty ID found on the front of the charger.
3. **Test Code Entry:** Liberty will provide a test code for the charger. Enter this code to verify charger operation.
It is best to have an EV to test the charger, however, this is not a requirement.
4. **Test Confirmation:** Once all EV chargers at the location are tested, the commissioning process is complete.

Note: Commissioning is necessary to activate this product's 3-year warranty.

Need Assistance?

Contact Liberty Plugins Support toll-free at (855) 387-3783.